

FOOT LOCK ASSEMBLY FOR 5-1/2" WIDE PATIO DOOR



Note: Please ensure block and Foot lock holes align properly before installation

- 1 Place and pre-drill with a 1/8" bit the foot lock and block onto the vertical sash meeting rail on the operator sash and thermo, ensure door is in the close position
- 2 Caution: this screw will be very close to the thermo
- 3 Place foot lock 1/8" from top edge of high profile sill
- 4 Place keeper 16mm from bottom of sill

1 4 2 3